

Eye Power

This project contains 5 Python files, and a folder [/eye] that contains the images training and test images.

1. **Utils.py:** Contains functions used by the other 4 Py files. All functions were written as methods within the *Utils* class. The CNN model is also found in this file.
2. **capture_training_images.py:** Launches a window with a yellow dot against a black background. Users should
 - a) maximize the window so that it covers the entire screen
 - b) fix the position of your right eye relative to the screen
 - c) cover the left eye, and focus the right eye on the yellow dot
 - d) press 'c' to capture and save JPEGs of the right eye in eye/train
 - e) repeat d) until desired number of training files have been saved
3. **train_test_split.py:** Transfers 10% of the images in eye/train to eye/test. Ratio is adjustable.
4. **train_cnn.py:** Trains the CNN using the image files in eye/train and eye/test folders. Saves the model weights in "eye_model.hdf5". Run this file only if you wish to train the model.
5. **demo.py:** Loads the model weights from "eye_model.hdf5", and launches a window with a green dot which you can control with your right eye.

Additional Info:

- The scripts are designed to detect human eyes using Haar Cascades (a function within OpenCV). It's a bit like a pre-trained object detector for different objects. The one used here is for the right eye. More info: <https://towardsdatascience.com/object-detection-with-haar-cascades-in-python-ad9e70ed50aa>

Basic OpenCV Commands and APIs

- **Basic Imports**

```
Import numpy as np
Import matplotlib.pyplot as plt
Import cv2
From PIL import Image
```

- **Load and display an image with PIL.** Images imported using PIL need to be converted into numpy arrays first.

```
pic = Image.open('../DATA/file.jpg')
pic_array = np.array(pic)
plt.imshow(pic[:, :, 0], cmap='gray') #Show image
```

- **Reading an image directly using cv2**

```
pic = cv2.imread('../DATA/file.jpg')
type(pic) → numpy.ndarray
```

- **Images imported using cv2 will be in BGR colour format. We need to convert it into other colour models for proper viewing using matplotlib.**

```
img = cv2.imread('data/file.jpg')
img = cv2.cvtColor(img, cv2.COLOR_BGR2RGB) #RGB
img = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY) #Gray scale
```

- **Resize an image (absolute and by ratio)**

```
# Absolute
new_img = cv2.resize(img, (1000,600)) # width, height
plt.imshow(new_img)

# Ratio
w_ratio = 0.3
h_ratio = 0.5
new_img = cv2.resize(img, (0,0), w_ratio, h_ratio)
```

- **Flip an image**

```
new_img = cv2.resize(img, (1000,600)) # width, height
plt.imshow(new_img)

w_ratio = 0.3
h_ratio = 0.5
new_img = cv2.resize(img, (0,0), w_ratio, h_ratio)
```

- **Save an image**

```
cv2.imwrite('image_file.jpg', new_img)
```

Draw on Images

- **Create a blank image**

```
img = np.zeros((512,512,3), dtype=np.int16)
```

- **Draw shapes.** Shapes are immediately rendered onto the image when the function is called.

```
cv2.rectangle(img,
               pt1=(100,200), # top left
               pt2=(300,400), # bottom right
               color=(255,0,0),
               thickness=5)
cv2.circle(img,
            pt1=(100,200),
            pt2=(300,400),
            color=(255,0,0),
            thickness=-1) # -1 indicates fully shaded circle
cv2.line(img,
          pt1=(100,200), # start
          pt2=(300,400), # end
          color=(255,0,0),
          thickness=5)

plt.imshow(img)
```

- **Rendering text**

```
font = cv2.FONT_HERSHEY_SIMPLEX
cv2.putText(img,
            text='Hello my text',
            fontFace=font,
            fontScale=1, # font size
            color=(255,255,255),
            thickness=4,
            org=(100,200),
            lineType=cv2.LINE_AA)

plt.imshow(img)
```

- **Polygon Drawing.** Need to define the vertices of the polygon first.

Working with Videos

- **Loading and editing a video.** The *VideoCapture* function is not designed for people to view videos. It is designed to loop over the images for editing and calculation. To view the video normally, we have to add a time delay equivalent to $1/\text{fps}$.

```
import cv2
import time

fps = 20

cap = cv2.VideoCapture('video.mp4')

if cap.isOpened() == False:
    #Check if initialised
    print("File not found or wrong CODEC")

while cap.isOpened():
    # ret is will be True if frame is read correctly.
    # ret will be False if it comes to the end of the video.
    ret, frame = cap.read()

    if ret==True:

        # Optional for viewing purposes
        time.sleep(1/fps)

        cv2.imshow('display_window', frame)

        if cv2.waitKey(10) & 0xFF==ord('q')
            break

    else:
        break

cap.release()
cv2.destoryAllWindows()
```

- **Draw static shapes on videos.** Shapes are immediately rendered onto the image when the function is called.

```
cap = cv2.VideoCapture(0) # Uses webcam

w = int(cap.get(cv2.CAP_PROP_FRAME_WIDTH))
h = int(cap.get(cv2.CAP_PROP_FRAME_HEIGHT))

# draw a rect starting at w/2 and h/2, of dim 10 by 15
x=w/2
y=h/2
x_dim= 10
y_dim= 15

while True:
    ret, frame = cap.read()

    # Draw the rectangle here
    cv2.rectangle(frame,
                  pt1=(x,y),
                  pt2=(x+x_dim, y+y_dim),
                  thickness=5,
                  color=(225,225,255))

    cv2.imshow('display_window', frame)

    if cv2.waitKey(10) & 0xFF == 27:
        break

cap.release()
cv2.destroyAllWindows()
```